

To open ZipTest Pro3:

- Go into the "Home" screen
- Hit the green diamond, and then 3
- Wait for the program to load
- Choose "new" or "continue"

To run DTL:

- Hit F3
- Hit 1, or "Enter" on 1
- Choose program 1
- Enter in required data, using the arrows to move between boxes (leave CFM50 blank)
- When finished with DTL, hit "ESC" to return to the ZipTest Pro3 page

To run ASHRAE 62.2:

- Hit F1
- Hit 2, or arrow down to 2 and "Enter"
- Hit "Enter", to choose 1
- Enter in all required data, using the arrows to move between boxes
- To enter in existing fans/windows, change "Use Alt Comp Tool?" to "Yes"
- Then enter in if baths/kitchens are affected (yes/no), and then will have to enter #s
- When finished with 62.2, hit "Enter" to return to the ZipTest Pro3 page

To exit ZipTest Pro3, hit the 2nd key, and then F2 (F7)

To open ZipTest Pro3:

- Go into the "Home" screen
- Hit the green diamond, and then 3
- Wait for the program to load
- Choose "new" or "continue"

To run DTL:

- Hit F3
- Hit 1, or "Enter" on 1
- Choose program 1
- Enter in required data, using the arrows to move between boxes (leave CFM50 blank)
- When finished with DTL, hit "ESC" to return to the ZipTest Pro3 page

To run ASHRAE 62.2:

- Hit F1
- Hit 2, or arrow down to 2 and "Enter"
- Hit "Enter", to choose 1
- Enter in all required data, using the arrows to move between boxes
- To enter in existing fans/windows, change "Use Alt Comp Tool?" to "Yes"
- Then enter in if baths/kitchens are affected (yes/no), and then will have to enter #s
- When finished with 62.2, hit "Enter" to return to the ZipTest Pro3 page

To exit ZipTest Pro3, hit the 2nd key, and then F2 (F7)