

ESTIMATED POST-WX BLOWER DOOR

based on volume of house

Pre-WX Blower Door	House Volume											
	6000	8000	10000	12000	14000	16000	18000	20000	22000	24000	26000	
1000	700	800	850	950	1000	1000	1000	1000	1000	1000	1000	1000
1200	800	900	950	1050	1100	1150	1200	1200	1200	1200	1200	1200
1400	900	1000	1050	1150	1200	1250	1350	1400	1400	1400	1400	1400
1600	1000	1100	1150	1200	1300	1350	1450	1500	1600	1600	1600	1600
1800	1100	1200	1250	1300	1400	1450	1550	1600	1700	1750	1800	1800
2000	1200	1250	1350	1400	1500	1550	1650	1700	1800	1850	1950	1950
2200	1300	1350	1450	1500	1600	1650	1750	1800	1900	1950	2050	2050
2400	1400	1450	1550	1600	1700	1750	1850	1900	2000	2050	2150	2150
2600	1500	1550	1650	1700	1800	1850	1950	2000	2100	2150	2250	2250
2800	1600	1650	1750	1800	1900	1950	2050	2100	2200	2250	2350	2350
3000	1700	1750	1850	1900	2000	2050	2150	2200	2300	2350	2400	2400
3200	1800	1850	1850	2000	2100	2150	2250	2300	2350	2450	2500	2500
3400	1900	1950	2050	2100	2200	2250	2350	2400	2450	2550	2600	2600
3600	2000	2050	2150	2200	2300	2350	2400	2500	2550	2650	2700	2700
3800	2100	2150	2250	2300	2400	2450	2500	2600	2650	2750	2800	2800
4000	2200	2250	2350	2400	2450	2550	2600	2700	2750	2850	2900	2900
4200	2300	2350	2400	2500	2550	2650	2700	2800	2850	2950	3000	3000
4400	2400	2450	2500	2600	2850	2750	2800	2900	2950	3050	3100	3100
4600	2450	2550	2600	2700	2750	2850	2900	3000	3050	3150	3200	3200
4800	2550	2650	2700	2800	2850	2950	3000	3100	3150	3250	3300	3300
5000	2650	2750	2800	2900	2950	3050	3100	3200	3250	3350	3400	3400

The chart above is an average CFM reduction recorded for several years based on the volume of the house. Across the top of the chart is the house volume. Along the left side is the pre-WX blower door reading. Follow the pre-WX blower door reading across to the closest volume number of the house to find the average post CFM reduction.